


Frame Center's Guide to Hanging Frame with Double Z Bars

What you need

- pencil
- ruler/measuring tape
- level
- screws (anchors if needed)
- drill
- Z bars (provided)




Hold your frame to the wall and mark where you would like the top center to sit.




On the back of your frame slide your z bars under the z bars already attached to the frame. Measure from the top edge of your frame down to the circular holes on each of your unattached z bars.



Mark these measurements on your wall from the top center point.




Center your top z bar on the wall with the mark you made. Make sure it is level and use a pencil to mark where each hole lines up.



Repeat the last step with your bottom z bar.



Use a drill to screw both of your z bars into the wall (you may need to predrill or use anchors depending on your wall).



Slides the z bars of your frame onto the z bars attached to the wall and make sure that they are lined up on the sides.



Share online and tag us!

Check out our Socials for more inspo/help

